



# Universal remote control

## Introduction

It's sometimes relevant to use an infrared universal remote control instead of the remote supplied with your Swisscom TV-Box.

Logitech announced recently they will stop selling «Harmony» infrared universal remote controls. Existing Harmony remotes will continue working, and Logitech claimed the Harmony support will be maintained. So, Swisscom TV-Boxes (TV-Box (UHD), Swisscom Box et Swisscom Box 21) will continue working with Harmony remotes. On the other hand, most of the «One for All» universal remotes are also compatible with Swisscom TV-Boxes.

With the information below, you will be able to program your infrared universal remote control for Swisscom blue TV.

## Using a universal infrared remote control

To use an infrared universal remote control with the Swisscom TV-Box (TV-Box (UHD), Swisscom Box and Swisscom Box 21), you must acquire the optional infrared receiver:  
<https://www.swisscom.ch/en/residential/products/tv/details.html/ip1800-infrarotempfaenger-10203085>

If you own an infrared universal remote control that can be programmed with an app or an online service, you can set it up by «injecting» the following codes («cff» format for Philips Pronto range, those codes can be converted into the appropriate format for your remote).

**Warning!** Swisscom cannot offer support for your programmable infrared remote control setup. If you need help, please contact a private installer.

### cff codes for Swisscom blue TV decoders

#### Power key

0000 006D 0000 000C 000C 0018 0018 0018 0018 0018 0018 000C 000C 0018 0018 0018 000C 000C 000C 0018 0018 0018 000C 000C 0018 000C 0D32

#### Mute key

0000 006D 0000 000B 000C 0018 0018 0018 0018 0018 0018 000C 000C 0018 0018 0018 0018 0018 0018 0018 000C 000C 0018 0018 000C 0D32

#### Fast rewind key

0000 006D 0000 000B 000C 0018 0018 0018 0018 0018 0018 000C 000C 0018 0018 0018 0018 0018 000C 000C 000C 000C 0018 0018 0018 0D3E

#### Record key

0000 006D 0000 000C 000C 0018 0018 0018 0018 0018 0018 000C 000C 0018 0018 0018 000C 000C 0018 000C 000C 000C 0018 000C 000C 0018 0D3E

#### Fast forward key

0000 006D 0000 000C 000C 0018 0018 0018 0018 0018 0018 000C 000C 0018 0018 0018 0018 0018 000C 000C 000C 000C 0018 000C 000C 0018 000C 0D32



### **Skip back key**

0000 006D 0000 000C 000C 0018 0018 0018 0018 0018 0018 000C 000C 0018 0018 0018 0018  
0018 000C 000C 000C 000C 000C 000C 0018 0018 000C 0D32

### **Play/Pause key**

0000 006D 0000 000C 000C 0018 0018 0018 0018 0018 0018 000C 000C 0018 0018 0018 000C  
000C 0018 000C 000C 0018 0018 000C 000C 0018 000C 0D32

### **Skip forward key**

0000 006D 0000 000B 000C 0018 0018 0018 0018 0018 0018 000C 000C 0018 0018 0018 0018  
0018 000C 000C 0018 0018 000C 000C 0018 0D3E

### **Back key**

0000 006D 0000 000C 000C 0018 0018 0018 0018 0018 0018 000C 000C 0018 0018 0018 000C  
000C 0018 000C 000C 000C 000C 000C 000C 0018 0018 0D3E

### **Previous channel key**

0000 006D 0000 000C 000C 0018 0018 0018 0018 0018 0018 000C 000C 0018 0018 0018 000C  
000C 0018 000C 000C 0018 000C 000C 000C 000C 0018 0D3E

### **Home key**

0000 006D 0000 000B 000C 0018 0018 0018 0018 0018 0018 000C 000C 0018 0018 0018 0018  
0018 0018 000C 000C 0018 0018 0018 000C 0D32

### **Cursor up key**

0000 006D 0000 000C 000C 0018 0018 0018 0018 0018 0018 000C 000C 0018 0018 0018 000C  
000C 000C 000C 0018 000C 000C 0018 000C 000C 0018 0D3E

### **Cursor down key**

0000 006D 0000 000C 000C 0018 0018 0018 0018 0018 0018 000C 000C 0018 0018 0018 000C  
000C 000C 000C 0018 000C 000C 0018 0018 0018 000C 0D32

### **Cursor left key**

0000 006D 0000 000C 000C 0018 0018 0018 0018 0018 0018 000C 000C 0018 0018 0018 000C  
000C 000C 000C 0018 000C 000C 000C 000C 0018 0018 0D3E

### **Cursor right key**

0000 006D 0000 000C 000C 0018 0018 0018 0018 0018 0018 000C 000C 0018 0018 0018 000C  
000C 0018 0018 000C 000C 000C 000C 000C 000C 0018 0D3E

### **OK key**

0000 006D 0000 000D 000C 0018 0018 0018 0018 0018 0018 000C 000C 0018 0018 0018 000C  
000C 000C 000C 0018 000C 000C 000C 000C 000C 000C 0018 000C 0D32

### **Guide key**

0000 006D 0000 000D 000C 0018 0018 0018 0018 0018 0018 000C 000C 0018 0018 0018 000C  
000C 0018 000C 000C 000C 000C 000C 000C 000C 000C 0018 000C 0D32

### **Option key**

0000 006D 0000 000C 000C 0018 0018 0018 0018 0018 0018 000C 000C 0018 0018 0018 000C  
000C 0018 0018 0018 000C 000C 000C 000C 0018 000C 0D32

### **Volume + key**

0000 006D 0000 000C 000C 0018 0018 0018 0018 0018 0018 000C 000C 0018 0018 0018 000C  
000C 0018 0018 000C 000C 0018 000C 000C 0018 000C 0D32



### **Volume - key**

0000 006D 0000 000B 000C 0018 0018 0018 0018 0018 0018 000C 000C 0018 0018 0018 000C  
000C 0018 0018 0018 0018 0018 0018 000C 0D32

### **Channel + key**

0000 006D 0000 000B 000C 0018 0018 0018 0018 0018 0018 000C 000C 0018 0018 0018 000C  
000C 0018 0018 0018 0018 000C 000C 0018 0D3E

### **Channel - key**

0000 006D 0000 000B 000C 0018 0018 0018 0018 0018 0018 000C 000C 0018 0018 0018 000C  
000C 0018 0018 0018 000C 000C 0018 0D3E

### **1 key**

0000 006D 0000 000D 000C 0018 0018 0018 0018 0018 0018 000C 000C 0018 0018 0018 000C  
000C 000C 000C 000C 000C 000C 000C 000C 000C 0018 0018 000C 0D32

### **2 key**

0000 006D 0000 000C 000C 0018 0018 0018 0018 0018 0018 000C 000C 0018 0018 0018 000C  
000C 000C 000C 000C 000C 000C 000C 0018 0018 0018 0D3E

### **3 key**

0000 006D 0000 000D 000C 0018 0018 0018 0018 0018 0018 000C 000C 0018 0018 0018 000C  
000C 000C 000C 000C 000C 000C 000C 0018 000C 000C 0018 000C 0D32

### **4 key**

0000 006D 0000 000C 000C 0018 0018 0018 0018 0018 0018 000C 000C 0018 0018 0018 000C  
000C 000C 000C 000C 000C 0018 0018 000C 000C 0018 0D3E

### **5 key**

0000 006D 0000 000C 000C 0018 0018 0018 0018 0018 0018 000C 000C 0018 0018 0018 000C  
000C 000C 000C 000C 000C 0018 0018 0018 0018 000C 0D32

### **6 key**

0000 006D 0000 000C 000C 0018 0018 0018 0018 0018 0018 000C 000C 0018 0018 0018 000C  
000C 000C 000C 000C 000C 0018 000C 000C 0018 0018 0D3E

### **7 key**

0000 006D 0000 000D 000C 0018 0018 0018 0018 0018 0018 000C 000C 0018 0018 0018 000C  
000C 000C 000C 000C 000C 0018 000C 000C 000C 000C 0018 000C 0D32

### **8 key**

0000 006D 0000 000C 000C 0018 0018 0018 0018 0018 0018 000C 000C 0018 0018 0018 000C  
000C 000C 000C 0018 0018 000C 000C 000C 000C 0018 0D3E

### **9 key**

0000 006D 0000 000C 000C 0018 0018 0018 0018 0018 0018 000C 000C 0018 0018 0018 000C  
000C 000C 000C 0018 0018 000C 000C 0018 0018 000C 0D32

### **0 key**

0000 006D 0000 000B 000C 0018 0018 0018 0018 0018 0018 000C 000C 0018 0018 0018 000C  
000C 000C 000C 0018 0018 0018 0018 0018 0D3E

### **Teletext key**

0000 006D 0000 000A 000C 0018 0018 0018 0018 0018 0018 000C 000C 0018 0018 0018 0018  
0018 0018 0018 0018 0018 0018 0D3E

**Radio key**

0000 006D 0000 000C 000C 0018 0018 0018 0018 0018 0018 000C 000C 0018 0018 0018 0018  
0018 000C 000C 0018 000C 000C 000C 000C 0018 000C 0D32

**Red key**

0000 006D 0000 000B 000C 0018 0018 0018 0018 0018 0018 000C 000C 0018 0018 0018 0018  
0018 000C 000C 0018 0018 0018 0018 000C 0D32

**Green key**

0000 006D 0000 000B 000C 0018 0018 0018 0018 0018 0018 000C 000C 0018 0018 0018 0018  
0018 000C 000C 0018 000C 000C 0018 0018 0D3E

**Yellow key**

0000 006D 0000 000C 000C 0018 0018 0018 0018 0018 0018 000C 000C 0018 0018 0018 0018  
0018 000C 000C 0018 000C 000C 000C 000C 0018 000C 0D32

**Blue key**

0000 006D 0000 000B 000C 0018 0018 0018 0018 0018 0018 000C 000C 0018 0018 0018 0018  
0018 0018 0018 000C 000C 000C 000C 0018 0D3E

**Note:**

The «source selection» and «microphone» keys cannot be used with an infrared universal remote control.