

WLAN-Booster setup

The best WLAN for your home

(Deutsch auf der Rückseite)



For more informations:
www.swisscom.ch/wlanbooster

Swisscom (Switzerland) Ltd
Contact Center
CH-3050 Bern

www.swisscom.ch
0800 800 800

06/2014 EN

Start You have received:



1 Is your Internet set up?




Your Internet-Box must be installed and switched on.

2 Attach the 3 aeriels.



1. Screw in the aeriels.
2. Flip them up.

3 Switch on the WLAN-Booster.




Plug in the power cable and press the power button.


Your WLAN-Booster is now set up.



Installation overview




4 Connect the WLAN-Booster to the Internet-Box.



Use the enclosed Ethernet cable.
Longer Ethernet cables are available in Swisscom Shops.

11 Alternatively: you can attach the stand to the base of the device.

You can further optimise your WLAN reception.



10 To do so position the aeriels appropriately.

5 Recommended: switch off the WLAN on the Internet Box.



If the Internet-Box is not in the same room as the WLAN-Booster, you can leave the WLAN turned on.

> Select «WLAN» over the Internet-Box display and then «Switch Off».
> **Centro Router:** push the WLAN button . If it no longer is lit, this means that the WLAN is deactivated.


If your device is not compatible with WPS, please use the WLAN information to connect manually.



The WLAN name (SSID) and password are on the bottom of the WLAN-Booster.


Find out how to change this data at www.swisscom.ch/wlanbooster

9 Use WPS to easily connect your devices to the WLAN-Booster.



Press the WPS button 2 seconds until the Power LED of the WLAN-Booster starts blinking. Then activate WPS on the device you want to connect.

8 Your WLAN-Booster has a dual band WLAN (2.4 GHz and 5 GHz).



Your connected devices select the best WLAN band automatically in each situation.

7 **6** Wait until the two WLAN LEDs go on.

